



# Vane

## User's Manual



SEE THE POTENTIAL

Renewable NRG Systems | Hinesburg, Vermont 05461 | USA 802.482.2255 | [www.renewablenrgsystems.com](http://www.renewablenrgsystems.com)

Specifications are subject to change without notice.

© Renewable NRG Systems  
110 Riggs Road  
Hinesburg VT 05461  
Tel: 802-482-2255  
Fax: 802-482-2272  
e-mail: [sales@renewablenrgsystems.com](mailto:sales@renewablenrgsystems.com)

Table of Contents

- Customer Support..... 4**
- Introduction..... 5**
  - Using This Manual ..... 5**
- Vane Operation and Considerations ..... 6**
  - Output Circuit Operation..... 6**
  - Heater Operation ..... 6**
  - ESD and Circuit Protection..... 7**
    - Cable Shield Decision - Important.....7
  - Transport and Handling ..... 7**
- Cables ..... Error! Bookmark not defined.**
  - Hybrid Turbine Control Sensor Cables..... **Error! Bookmark not defined.**
  - Compatible Cables for Hybrid Turbine Control Sensors..... **Error! Bookmark not defined.**
- Installation and Technical Drawings ..... 9**
  - Mounting Mast Orientation ..... 9**
  - Prepare Shield ..... 9**
  - Mount Connector..... 10**
  - Connect Cable to Controller ..... 12**
  - Mount Sensor ..... 12**
  - Technical Drawing..... 13**
  - Technical Specifications..... 14**
- Appendix A: Grounding and Bonding Hybrid™ sensors for over-voltage protection ..... 16**
  - Introduction ..... 16**
  - Recommended Practices..... 16**
  - Sensor Construction Notes..... 17**
  - References ..... 18**
- Appendix B: Warranty & Repair ..... 19**
- Sending Items for Repair ..... 20**
  - INTERNATIONAL CUSTOMERS ..... 20
  - International Customers: ..... 20
  - US CUSTOMERS ..... 20

## Customer Support

Renewable NRG Systems offers a variety of support options to help you get the most from your RNRG product. If you have questions about your RNRG product, first look in the printed product documentation or the Knowledge Base in the Tech Support section of Renewable NRG Systems' web site. If you cannot find the answer, contact your salesperson or Renewable NRG Systems Technical Support for assistance using the information below. Customer support is available 8:30 AM to 5:00 PM EST, Monday through Friday.

**Renewable NRG Systems**  
**110 Riggs Road**  
**Hinesburg, Vermont**  
**05461 U.S.A.**

**Telephone: 802-482-2255**  
**Toll Free (USA only): 800-448-WIND (800-448-9463)**  
**FAX: 802-482-2272**  
**Email: [support@renewablenrgsystems.com](mailto:support@renewablenrgsystems.com)**

When you call or email, you should have the appropriate product documentation at hand and be prepared to give the following information:

- Customer name
- Who purchased equipment
- Item number or description
- Serial number
- When equipment was purchased
- Where equipment is installed - terrain conditions
- Description of the problem with some detail
- What events took place leading up to the problem
- What you have tried while attempting to solve the problem

Renewable NRG Systems maintains an extensive website which includes an in-depth customer support area for RNRG customers. If you need assistance at times other than our regular business hours, we suggest visiting our website, **[www.renewablenrgsystems.com](http://www.renewablenrgsystems.com)**.

All instruments, sensors, software and towers manufactured by Renewable NRG Systems are designed to be reliable and easy to use. We welcome your comments and appreciate your help in making RNRG products the best available.

# Introduction

The RNRG Hybrid vane is an electrically heated wind direction sensor designed for wind turbine control and wind resource assessment. The sensor is mounted to the turbine nacelle or meteorological mast and provides an electrical output signal with frequency proportional to wind direction. Although the Hybrid sensors can be used for meteorological work, this manual is specific to turbine control applications. However, there should be little difficulty in adapting these sensors for meteorological applications.

The Hybrid is rugged enough to accurately measure wind directions in excess of 70 m/s (156 mph), yet its relatively low moment of inertia permits it to respond rapidly to gusts and lulls. It is built with corrosion resistant materials and finishes, and is sealed against wind-driven rain and dust.

The Hybrid sensor line has a captive mounting system with integral connector that allows quick and easy changing of the sensor. There are only three internal components (electronics module, heater assembly and bearing assembly) for ease of maintenance. The Hybrid also has a spare label pocket for a customer-supplied identification label.

## Using This Manual

Read this manual completely before installing and operating the Hybrid vane. Follow all instructions and recommendations closely.

This document and the sensor may use the following symbols:



Earth (Ground)



Chassis Ground



AC Voltage



AC or DC Voltage



DC Voltage



Hot Surface



Warning


This typeface within the body of the manual is used for general descriptions and instructions to the user.

*This typeface is used to warn users of a potential danger, either to themselves or to the sensor.*

# Vane Operation and Considerations

## Output Circuit Operation

The Hybrid vane provides a square wave output signal with a frequency proportional to the head rotation position. The square wave amplitude is determined by the power supply voltage.



**Vane Output Waveform**

**Output frequency proportional to wind direction**

The frequency varies between 100Hz and 459Hz. At 100 Hz, the direction is 0 degrees and at 459 Hz the direction is 359 degrees (1 degree per Hz). Note that the output signal will equal 280 Hz (180 degrees) when the vane is aligned with the rotor. If the frequency output is 0 Hz, this indicates a fault condition. The most likely causes would be: no power, wiring problem, or a failed sensor.

If you were to look at the signal on an oscilloscope, you would notice that the rising edges fluctuate back and forth from cycle to cycle. This is normal and was designed this way for RNRG factory use. This will not affect your frequency counter in any way. However, if you are using a "time per pulse" measurement method you will want to trigger on the falling edges only. For best accuracy, time and count many cycles then divide the count by the time for an average frequency. This technique also effectively filters out short-term wind direction variations.

## Heater Operation

The heat source for the Hybrid is a self-regulating, constant-temperature heater. In severe wind and icing conditions, the Hybrid draws more power to help remain clear of ice. As conditions improve, the Hybrid draws less power. The Hybrid's self-regulating feature increases reliability, insuring that the head does not reach excessive temperatures. Excessive temperatures can stress bearing lubricants, wiring, and present a hazard in the presence of combustible materials. The Hybrid's heater is powered by 24 volt power, AC or DC, making it compatible with a wide range of turbine controller power supplies and remote site equipment. An optional 120 / 240 V to 24 V AC transformer is also available.

- Following a brief inrush current, after approximately 30 seconds, the heater settles into its temperature controlled mode.
- It is recommended that a 15 A slow-blow fuse be placed in-line with the heater.



Warning: Sensor surfaces (particularly the head and the upper body) can become quite hot and may burn you; especially in warm ambient conditions.

*Use caution when the heater power is on!*

### ***ESD and Circuit Protection***

The Hybrid sensor has been designed to withstand most common wiring errors and electrostatic discharge. These include reversed polarity on the power supply inputs, applying power to or shorting the signal output lines, and electrostatic discharge on any line.

*However, the sensor is not indestructible. Avoid applying more than the rated power supply to any pin. While extremely rugged, nearby or direct lightning strikes may damage the sensor.*

### **Cable Shield Decision - Important**

The user must decide how to connect the shield of the signal cabling for their application. This is an important part of the overall design of the lightning protection and grounding system for each turbine design. Reference information can be found in Appendix A.

We recommend that the shield always be connected at the controller end of the cable. This provides shielding against capacitively (electrostatically) coupled interference to the sensor signal.

If the shield can be connected to ground at the sensor boom as well, the shield can also provide protection against inductive (magnetically) coupled noise sources, such as generator noise and lightning electromagnetic pulses. However, you should connect the shield at both ends ONLY if the turbine grounding system provides sufficient bonding and grounding to prevent ground loop currents in the shield wire.

On the RNRG-cable assembly for the Hybrid Turbine Control Sensor, the shield drain wire is available for connection at both ends. If the sensor end is not to be connected, cut off the shield wire at the sensor end before installation to prevent accidental contact to the sensor mount.

### ***Transport and Handling***

This sensor is a precision instrument. Please use care in its handling to protect the bearings and shaft. It is recommended that the sensor be carefully placed on its side instead of standing up.

*If the sensor should tip over onto a hard surface, bearing or shaft damage may occur. Use care!*

# Cables

## Hybrid Turbine Control Sensor Cables

Item Number	Description	Notes
4716	Assembly-Cable,600V, 10m, Connector, Power, Signal, WithMountingBolt, Hybrid TCS	10 m length, 5 pin cable, <b>Green Tag</b>
4717	Assembly-Cable,600V,20m, Connector,Power,Signal, WithMountingBolt,Hybrid TCS	20 m length, 5 pin cable, <b>Green Tag</b>

## Compatible Cables for Hybrid Turbine Control Sensors


Item Number	Description	Compatible Cables
3733	Sensor-Hybrid Turbine Control Sensor, Vane	4716, 4717
3734	Sensor-Hybrid Turbine Control Sensor, Anemometer	4716, 4717
4183	Sensor-Hybrid Turbine Control Sensor, Anemometer (calibrated)	4716, 4717



# Installation and Technical Drawings

## Mounting Mast Orientation


Refer to the technical drawing for details on mounting mast design. Orient the cross-holes in the top of the mounting mast such that they are lined up parallel to the turbine nacelle centerline.




**Align cross-holes parallel to nacelle centerline.**

## Prepare Shield

Based on your decision about the cable shield connection scheme (see previous section and Appendix A), cut off or attach the shield to the mounting mast. If you choose to cut the shield wire, make sure to cut it off short enough to avoid touching the mounting mast or bolt.




**Prepare shield**




**If cutting shield wire, cut close to connector base as shown.**

## Mount Connector


Remove the nut, washer, and bolt from the connector. Feed the cable through the mounting mast until the connector reaches the mast. Align the bolt hole in the connector with the holes in the mounting mast such that the "TOWARD ROTOR" text molded onto the connector leg is oriented toward the turbine rotor. If you are connecting the shield to the mounting mast, do so now.



**Remove the nut, washer, & bolt.**



**Feed cable through mast.**




**Install connector with "TOWARD ROTOR" text pointing to the rotor.**

Be sure that the connector is snug against the top of the mounting mast and that the washer is on the bolt (compression of the rubber washer may be necessary) then pass the bolt through the mast and connector. Now attach the nut to the bolt a few turns until the nylon patch is in contact with the nut. The nylon patch prevents the nut from backing off the bolt threads. Note that the washer is between the mounting mast and the bolt head.




**Secure connector to mast with bolt, washer, and nut.**

The Hybrid sensors have four ridges running vertically inside the body's lower end as shown in the picture below. These ensure that the sensor mounts securely on the mounting mast.



If attaching the shield to the ground screw, make sure that it does not interfere with the mounting ridges by running it straight down the mast from the connector to the ground screw. Do not wrap the wire around the mast. The picture below shows the ground screw attachment option.



**Suggested method for attaching shield to mast.**

### Connect Cable to Controller

Route the sensor cable into the nacelle and to its connection point. It may be helpful to label the end of each wire before pulling the cable to its connection point. Following the color code, connect the sensor wires and shield wire to the turbine controller and heater power supply.

Sensor Common	Black, 22 AWG
Sensor Power	Red, 22 AWG
Sensor Signal	White, 22 AWG
Heater Power A	Orange/White, 20 AWG
Heater Power B	Orange/Black, 20 AWG


### Mount Sensor

To attach the sensor to the mounting mast, slide the clamp bolt and washer away from the mounting mast until the nut is against the mounting mast and is hanging vertically. Rotate the Hybrid sensor body so that the "THIS SIDE TOWARD ROTOR" label is facing the turbine rotor. This aligns the internal key with the alignment slot in the connector. Now, slide the sensor down over the boom carefully making sure that the key drops into the slot. Continue to slide the sensor down until it is firmly seated on the nut. There will be some drag as the o-ring seal and the connector pins engage. Tighten the bolt using a 10 mm wrench to 7 N-m (5 ft-lbs). Replacement washers, nuts and bolts can be ordered from RNRG (part #4422).



**Slide sensor down over mast.**

# Technical Drawing



## Technical Specifications

Description	Sensor type	heated vane
	Applications	<ul style="list-style-type: none"> <li>wind turbine control</li> <li>wind resource assessment in icing environments</li> <li>environmental monitoring</li> </ul>
	Sensor range	0° to 360°, free rotation
	Instrument compatibility	digital inputs of turbine controllers, PLCs, or Symphonie logger
	Certifications	Conforms to UL Std 61010-1; Certified to CSA STD C22.2 NO. 61010-1
Output signal	Signal type	<ul style="list-style-type: none"> <li>high level square wave frequency (see manual for details)</li> <li>amplitude equals supply voltage</li> <li>other formats from optional personality module</li> </ul>
	Transfer function	<ul style="list-style-type: none"> <li>0° = 100 Hz to 359° = 459 Hz</li> <li>(280 Hz is center for turbine control applications)</li> <li>1° per Hz</li> </ul>
	Accuracy	within +/- 2 ° of transfer function
	Dead band	None
	Recommended load resistance	1200 Ω minimum
	Output signal range	<ul style="list-style-type: none"> <li>100 Hz to 459 Hz</li> <li>0 Hz output indicates fault</li> </ul>
	Resolution	1°
Response characteristics	Threshold	< 2 m/s (< 4.5 mph)
Power requirements	Supply voltage	8 to 24 V DC
	Supply current	<ul style="list-style-type: none"> <li>40 mA typical</li> <li>51 mA max. (not including heater)</li> </ul>
	Heater supply voltage	24 V, AC or DC
	Heater supply current	<ul style="list-style-type: none"> <li>self regulating</li> <li>1 to 4 A, thermal load dependant</li> <li>cold start inrush current: 9 A peak</li> <li>inrush drops below 4 A within 30 secs.</li> </ul>
Installation	Mounting	sensor housing compatible with: <ul style="list-style-type: none"> <li>25 mm pipe per BS1387, or</li> <li>32 mm tube, or</li> <li>1 inch IPS pipe</li> <li>1-1/4" Tube</li> </ul> quick disconnect allows for easy mounting or dismounting captive M6 clamp bolt, nut, and connector
	Tools required	10 mm wrench
	Accessories	<ul style="list-style-type: none"> <li>pre-wired cable assembly (not included)</li> <li>personality module (interface converter) (not included)</li> </ul>
	Wiring	sensor plugs onto captive connector - see manual for wiring details
Environmental	Operating temperature range	-40 ° C to 60 ° C ( -40 ° F to 140 ° F)
	Operating humidity range	0 to 100% RH (sealed against condensation)
Physical	Connections	<ul style="list-style-type: none"> <li>shield</li> <li>two heater wires (20 AWG)</li> </ul>

		<ul style="list-style-type: none"> <li>• three sensor wires: power, common, signal (22 AWG)</li> </ul>
	Weight	1.58 kg (3.5 lbs)
	Dimensions	<ul style="list-style-type: none"> <li>• overall height 252 mm (9.92 inches)</li> <li>• swept diameter: 213 mm (8.4 inches)</li> <li>• body diameter: 58 mm (2.3 inches)</li> </ul>
Materials	Wing	black anodized aluminum
	Body	zinc
	Shaft	stainless steel
	Bearing	double-shielded stainless steel ball bearings



# Appendix A: Grounding and Bonding Hybrid™ sensors for over-voltage protection

## *Introduction*

The purpose of this document is to outline NRG's recommended practices for wiring, grounding, and bonding of Hybrid™ turbine control sensors. The goal is to provide the best possible protection against direct and indirect lightning damage for both the sensor and the interconnected turbine systems.

This document also details the internal construction of the sensor's bonding and over-voltage protection. This allows the wind turbine designer to coordinate the sensor grounding and Over Voltage Protection (OVP) with the rest of the turbine's Lightning Protection System (LPS).

## *Recommended Practices*

The long-term reliability and the Electromagnetic Compatibility (EMC) performance of the sensor are dependent on proper installation and connections. These recommendations could apply to any control electronics or sensors, but are particularly critical for wind sensors because they are exposed on the top of the nacelle.

1. IEC 61400-24 classifies several Lightning Protection Zones (LPZ). LPZ 0<sub>A</sub> is exposed on the surface of the turbine and is subject to direct lightning attachment. The turbine must provide air terminals such as lightning rods to protect the sensors from direct lightning attachment. This creates an area in LPZ 0<sub>B</sub> to mount the sensors.
2. Careful routing of the lightning down-conductor and coordination of the grounding and bonding of the down-conductor(s) to the turbine's LPS is required to minimize the energy coupled into other systems such as the sensors. Provide maximum possible spacing between lightning down-conductors and any control cabling or raceway. Do not route any other cabling or raceway alongside the lightning down-conductors. These measures will minimize the coupling of lightning electromagnetic pulse (LEMP) energy into other turbine systems.
3. The Sensor body is metal, and bonds to the sensor mounting mast. The mounting mast must be metal. Take particular care to bond the sensor mounting mast to the turbine's LPS in coordination with the placement and bonding of the lightning air terminals and bonding of the turbine frame and nacelle.
4. Use shielded or "screened" cable with high shield coverage for sensor cabling. We recommend bonding the cable shield to the grounding system at both ends- at the sensor, and at the connection to the turbine control system- to provide maximum protection from LEMP. However, see note 6 about preventing ground loops. RNRG supplied cables provide a shield drain wire at the sensor end. If your LPS design does not use this shield drain, trim it off to prevent short circuits.
5. Run the sensor cabling in metallic raceway or conduit. Bond the raceway or conduit to the LPS at both ends. This provides protection for the sensor and cabling against EMI and LEMP.

The purpose of recommendations 1 through 5 is to provide shielding of the internal sensor electronics, heater, and cabling so that they are protected to LPZ 1, per IEC 61400-24.

Recommendations 6 and 7 relate to ground loops and over-voltage protection.




6. Provide sufficient bonding to prevent ground loop currents in the shields and raceways. Whenever possible, it is better to resolve the underlying grounding problems, rather than leaving the shield unconnected to prevent ground loop current flow.
7. Since the sensor's electronics and cabling are in LPZ 1, isolation and or over-voltage protection should be provided at the interface between the sensor cabling and turbine control system to provide LPZ 2 or better protection for the controller.

### ***Sensor Construction Notes***

The Hybrid™ turbine control sensor's enclosure is metal, which provides an overall EMI shield for the internal components of the sensor. The sensor includes internal over-voltage protection (OVP) components. For these features to be effective, the sensor must be installed and connected properly. The figure below shows the internal connection details of the sensor bonding and OVP.

The direction vane is shown as an example; the anemometer uses the same construction.



**Internal bonding and OVP of the Hybrid™ turbine control sensor**

## **References**

1. IEC TR 61400-24: 2002: *Wind Turbine Generator Systems- Part 24: Lightning Protection.*
2. IEC 61312-1: 1995: *Protection against Lightning Electromagnetic Impulse- Part 1: General Principles*

## Appendix B: Warranty & Repair

Renewable NRG Systems (RNRG) warrants its products for a period of two years from date of original purchase solely for the benefit of the original consumer purchaser. If this product is determined to be defective in materials or workmanship, RNRG will, at RNRG's option, repair or replace this product without charge. This warranty does not cover damage due to improper installation or use, accident or misuse, damages due to any unauthorized service or lightning. This warranty also will not apply if any seal on any instrument or sensor is broken, if any cable has been severed, or the equipment was not adequately grounded.

To return a defective product, request an RMA (return merchandise authorization) number by calling us at the number below or by emailing [support@renewablenrgsystems.com](mailto:support@renewablenrgsystems.com), or by submitting a request through our website's Technical Support area.

Please provide the serial number of the item as well as date of purchase. No products will be accepted for warranty work without an RMA number. The product must be returned, postage prepaid, to RNRG with a brief description of the problem, RMA number and a return address with phone number.

The foregoing limited warranty is given in lieu of all other warranties, express or implied. RNRG specifically disclaims all implied warranties including, but not limited to, any implied warranties of merchantability and fitness for a particular purpose.

The above limited warranty expressly excludes, and RNRG shall not be liable for, any incidental or consequential damages caused by or related to the selection, use of, inability to use or malfunction of this product.

RNRG will make a good faith effort to repair or replace promptly any product which proves to be defective within the warranty period. First, contact RNRG or the representative from whom the product was purchased and ask for an RMA number. Inspect your shipments for damage to packages or missing packages immediately upon receipt. Record any such exceptions on the freight receipt of the delivery agent. If any contents are damaged or missing, report this in writing to the freight carrier and send RNRG a copy of the damage report. If you insured the shipment yourself, report any damages to your insurance carrier.

Tel: 802-482-2255

Fax: 802-482-2272

email: [support@renewablenrgsystems.com](mailto:support@renewablenrgsystems.com)

website: <https://www.renewablenrgsystems.com/technical-support>

# Sending Items for Repair

## INTERNATIONAL CUSTOMERS

Contact Renewable NRG Systems by phone, email, or through our website to obtain an RMA number (Return Material Authorization). Write the RMA number clearly on all shipping cartons.

Tel: 802-482-2255 Fax: 802-482-2272

email: [support@renewablenrgsystems.com](mailto:support@renewablenrgsystems.com)

website: <https://www.renewablenrgsystems.com/technical-support>

**2. Send your item to Renewable NRG Systems "Delivery Duty Paid"** (see address below) using a door-to-door courier service such as UPS, FedEx, or DHL. If the repair is not urgent, please send your package by Airmail. (Courier services deliver the package directly to us, customs cleared.)

**Renewable NRG Systems will not accept packages shipped Freight Collect or with Collect charges.**

If Renewable NRG Systems refuses the shipment, the courier service will charge your account return freight charges.

**DO NOT send return items by direct or consolidated air freight service with an airline.**

The cost for air freight may seem lower than the courier service, but air freight costs do not include customs clearance, airport handling, break bulk fees, and inland delivery to Renewable NRG Systems.

**3. Attach a Commercial Invoice** to the carton. The Commercial Invoice should include the following information:

- Name and address of the shipper.
- Renewable NRG Systems' complete address and telephone number as the consignee.
- Description of the items being returned.
- Quantity of each item being returned.
- Value for customs / insurance (purchase price or replacement cost).
- Number of cartons with respective weights and dimensions.
- Please include the following statement to avoid paying US import duties:

"These items are being returned to their U.S. manufacturer. Country of manufacture and origin is USA, HTS CODE 9801.00.1012."

**4. Pack your repair item in a sturdy packing carton.** Tag each item with a brief description of the problem.

**5. Insure your shipment** against damage or loss in transit. Be sure to check the appropriate box and enter a "Value for Carriage" (insurance) on your air waybill. The value is the purchase price of the equipment or what it would cost to replace the equipment if the shipment were lost. Keep a record of the tracking number.

Once your item arrives, we will assess the item and notify you of the repair cost. Any repair charges and freight costs, if applicable, are payable before Renewable NRG Systems will return the repaired item to you via door-to-door courier service. Renewable NRG Systems will send you a shipment advisement when the repaired item is shipped.

## International Customers:

Before sending the repair item to Renewable NRG Systems, check with your local customs authorities about provisions in your country for exporting and re-importing repair items. Some countries treat repair shipments like new shipments and charge import duties and taxes again upon re-importation. Other countries have specific steps to follow or specific forms to complete which help reduce the import duties upon re-import of the item.

## US CUSTOMERS

Please see items 1, 4, and 5 above. Send your item(s) to Renewable NRG Systems "Freight Prepaid and Insured."

**Shipments sent freight collect will not be accepted by Renewable NRG Systems.**

Renewable NRG Systems  
Attn: RMA- \_\_\_\_\_  
110 Riggs Road  
Hinesburg VT 05461 USA



Global leaders in wind assessment technology

[www.nrgsystems.com](http://www.nrgsystems.com)

## Declaration of Conformity

(in accordance with ISO/IEC 17050-1:2004)

NRG Systems Document Number: N4441, Rev C

**Supplier:** NRG Systems  
**Supplier Address:** 110 Riggs Road, Hinesburg, VT 05461, USA  
Telephone: 802 482 2255, Fax: 802 482 2272  
Email: [sales@nrgsystems.com](mailto:sales@nrgsystems.com)

**Declares that the Product:** Hybrid Turbine Control Sensors  
**Including Model Numbers:**

Hybrid Turbine Control Anemometer	Item FG 3734
Hybrid Turbine Control Vane	Item FG 3733
Hybrid Personality Module	Item FG 3798
Hybrid 10M Cable	Item FG 3767
Hybrid 20M Cable	Item FG 4133

are in conformity with the requirements of the following standards:

**Safety:** IEC 61010-1 Ed. 2.0 b:2001, "Safety requirements for electrical equipment for measurement, control, and laboratory use"  
**EMC:** 2004/108/EC "Council Directive of 15 December 2004, on the approximation of the Laws of Member States relating to electromagnetic compatibility"  
EN61326-1:2006 Class B "Electrical Equipment for Measurement, Control, and Laboratory Use—EMC Requirements"

### Additional Information:

All circuits are extra low voltage (ELV), therefore standard 2006/95/EC (the low-voltage directive) does not apply, and


This product complies with the requirements of 2004/108/EC, and therefore

The product is CE marked in accordance with 93/68/EEC.

The design documentation, test reports, assessment laboratory accreditation, and technical construction file are on file with Mr. Barry King, Electrical Engineer.

Issued at Hinesburg, VT, USA

05 March, 2010

  
\_\_\_\_\_  
Owen Clay  
Engineering Manager

110 Riggs Road, PO Box 509, Hinesburg, Vermont 05461 USA • Tel 802-482-2255 • Fax 802-482-2272 • [info@nrgsystems.com](mailto:info@nrgsystems.com)